



1.
Loosen the lower screw in the ring.



2.
Hold the inner parts (the cylindrical shades) tight.



3.
Turn the ring to the position you want it.



4.
Tighten the lower screw again.
You might need to do this a few times
as the cable tends to turn over time.